# Firefly Simulator User's Manual

#### Introduction

The *firefly simulator* is a device that is used to illuminate light-emitting diodes (LEDs) in order to simulate the flashing of fireflies. The simulator allows the user to program (or *configure*) the brightness, duration, and other aspects of the LED flashes so that a wide variety of different kinds of flashes can be created. The heart of the firefly simulator is an Arduino microcontroller.

The simulated firefly behavior is described in terms of *LEDs*, *channels*, *flashes*, *patterns*, and *random pattern sets*. Each of these terms has a very specific meaning in this context. When using the simulator, true physical LEDs are connected by cables to the output channels of the simulator. Each channel corresponds to a numbered electrical connector on the side of the simulator enclosure. Within the simulator software a set of *virtual LEDs* can be defined, where a virtual LED consists of a specified channel and a specified maximum brightness level.

A virtual LED is then used to define a *flash*. A flash definition includes the choice of a specific virtual LED as well as the timing parameters that determine how quickly the LED changes from completely dark to fully illuminated, how long the LED stays fully illuminated, how quickly the LED changes to completely dark, and how long the LED must remain dark before another flash can begin.

One or more flashes can then be combined into a *pattern*. The flashes associated with a particular pattern are executed first, in the specified order, and then all LEDs are kept dark until the specified duration of the pattern ends.

Multiple patterns can be combined into a *random pattern set*. As the name suggests, the patterns specified in a random pattern set can be executed continuously in a random order.

The simulator is initially configured using a USB connection to a host computer. However, all configuration information is stored in nonvolatile memory within the simulator and a small keypad on the simulator itself can be used to execute flashing patterns. Thus, the simulator can be made portable and used in the field without a host computer.

#### **Connections**

#### Power/USB

A single USB connector on the simulator is used to supply power to the device as well as to support the interface with the host computer. The computer interface is actually an asynchronous serial interface that is emulated via USB. A description of the interface parameters and communication protocol is provided below.

### **Physical LEDs**

A *physical LED* consists of a small circuit board connected to a cable that can be connected to the simulator. An actual LED is mounted on the circuit board, as well as other components that are used to regulate and limit the electrical current through the LED.

Up to six physical LEDs can be simultaneously connected to the simulator, by plugging their cables into the six *LED channel* connectors on the side of the simulator.

It is the user's responsibility to mark each physical LED with a unique identifier and maintain records of the optical characteristics of that LED. It is also the user's responsibility to track which physical LED is connected to each LED channel.

#### **Abort Button**

The *abort button* is a red pushbutton located on the top of the simulator enclosure. Pressing this button will cause the simulator to be reset to its initial state, the same state that it is in when power is first applied. Some of the commands described below will cause the simulator to execute flashes continuously, and in that case pressing the abort button is necessary to halt the simulator.

#### **Communications**

The firefly simulator communicates with a host computer using a serial communications interface, which is called a COM port in Windows or a /dev/tty in Linux and MacOS. This interface can be used to configure the simulator and to log its operation.

The simulator has been programmed to operate at 9600 baud with 8 data bits, no parity, 1 stop bit, and no flow control.

The user can send commands to the simulator using a terminal simulator program on the host computer, and the simulator's responses will also appear on the terminal. The command messages sent by the host computer are simple strings of text. Each command begins with one or two **capital** letters, followed by some number of **fields** or **parameters** for the command. The different fields of a message are separated by a **comma**. Each command must be terminated with a carriage return and/or linefeed, which are typically added just by pressing the "Enter" key.

#### **Virtual LEDs**

The simulator software has no information about what, if any, physical LEDs are connected to its LED channels. Instead, the simulator software is configured to control *virtual LEDs*. A virtual LED is defined by assigning to it a physical LED channel number as well as a maximum brightness value (0 to 100). Note that the maximum brightness level is treated as a percentage of the maximum current available to the physical LED. For example, if a particular physical LED circuit board has been designed to limit the LED current to 20 mA, and then setting the maximum brightness of a virtual LED to 50, will result in an average LED current of 10 mA when the LED is "on".

Each virtual LED has a unique *LED number*, which is simply an integer used to identify a particular virtual LED so it can be used later. The simulator can typically store up to 16 distinct virtual LED definitions.

Note that a given LED channel (i.e. a given physical LED) can be used in more than one virtual LED definition. This allows the same physical LED to be used at different brightness levels.

The command message used to configure a virtual LED begins with the letter 'L' and has three fields: the virtual LED number, the LED channel number, and the maximum brightness level. The fields must be integer values. For example, the commands shown here will first configure virtual LED #7 to use the physical LED on channel 3 with a maximum brightness equivalent to 80% of its maximum possible current. Virtual LED #1 is then configured to use channel 2 with 100% of its maximum current. If the format of the command is correct and the fields have appropriate values, then the simulator will respond with "LED Configured". (For the examples shown in this document, the text typed by the user is shown in a bold typewriter font and the simulator's response is shown in a normal typewriter font. Note that all human-readable messages issued by the firefly simulator are subject to change with future versions of the simulator software.)

```
L,7,3,80

LED Configured

L,1,2,100

LED Configured
```

Note that once configured a virtual LED can be modified simply by rewriting its definition. Defining the same virtual LED number multiple times does not produce an error but only the last definition will be saved. The LED configuration command will fail if

- the LED number is out of range (1 to 16 for an Arduino UNO), or
- the channel number is invalid (1 to 6 for an Arduino UNO), or
- the maximum brightness is zero, or
- the maximum brightness is greater than 100

The DL (Dump LEDs) command will list all of the virtual LEDs that have been configured in the simulator. There are no additional fields for this command. Note that each virtual LED is listed using the same format as the command used to configure it, except that the first letter is a lower-case 'l'.

DL Saved LEDs 1,1,2,100 1,7,3,80

The XL (eXecute LED) command can be used to manually turn an LED on or off. This command has two fields: the virtual LED number and the desired brightness level. The brightness level must be from 0 to 100, and is a percentage of the maximum LED current. The commands shown below will turn on virtual LED #1 at 100% of its possible brightness, and then turn it off.

```
XL,1,100
Executing LED 1
XL,1,0
Executing LED 1
```

#### **Flashes**

A *flash* is the process of illuminating a given virtual LED for a given amount of time. In addition, the parameters of a flash specify a time interval from when the LED becomes dark until another flash can occur.

The timing parameters of a flash are shown in Fig. 1. At the beginning of a flash the illumination level of the LED may be increased linearly over a period of time, called the *up duration*, until the LED is fully illuminated at its maximum brightness level. Similarly, after the LED is kept at full illumination for its *on duration*, the illumination level may be linearly decreased over a period of time called the *down duration*. The total duration of a flash is its *interpulse interval*. If the sum of the up duration, on duration, and down duration is less than the interpulse interval then the LED will remain dark until the full interpulse interval time has elapsed.




Figure 1: flash waveform

The command message used to configure a flash begins with the letter 'F' and has six fields: the flash number, the virtual LED number, the up duration, the on duration, the down duration, and the interpulse interval. The fields must be non-negative integer values. All duration and interval times are specified in milliseconds; the up duration and down duration should be multiples of 10 ms.

For example, the commands shown below will configure flash #4 to use virtual LED #3. The LED's illumination will ramp up from fully dark to its maximum brightness in 200 ms, stay at maximum brightness for 300 ms, and then ramp down from maximum brightness to fully dark over 400 ms. The interpulse interval is specified as 1.2 s, and the LED is partially or fully illuminated for a total of 900 ms, so the LED will remain dark for an additional 600 ms before the next flash can begin.

```
F,4,3,200,300,400,1500
Flash Configured
```

Attempting to configure a flash number that is already configured will cause the new definition to replace the existing definition, without warning. If the format of the command is correct and the fields have appropriate values, then the simulator will respond with "Flash Configured". The command will fail if

- the flash number or LED number is out of range (1 to 16 for the Arduino UNO), or
- the up duration, on duration, or down duration is greater than 32.767 ms, or
- the interpulse interval is zero, or
- the interpulse interval is less than the sum of the up duration, on duration, and down duration.

The DF (Dump Flashes) command will list all of the flashes that have been configured in the simulator. There are no additional fields for this command. All configured flashes are listed, in numerical order. Note that flash #3 has not yet been configured in this example.

```
DF

f,1,1,120,500,150,2000

f,2,2,200,200,200,1000

f,4,3,200,300,400,1500

f,5,6,200,300,400,1200
```

The XF (eXecute Flash) command can be used to execute a specific flash. This command has one field, the flash number. The specified flash will be executed repeatedly and the simulator will not accept any further commands. The ABORT button must be pressed to terminate this command.

```
XF,4
Executing flash number 4
```

## **Patterns**

A *pattern* is the process of executing one or more flashes in a given amount of time. The set of flashes to be executed is called the *flash list*, which may contain up to 16 flash numbers. The flash numbers in the pattern can all be unique, or a given flash number may be repeated. In addition, the parameters of a pattern specify a time interval from when the last flash ends until another pattern can begin (the *flash pattern interval*).

The timing parameters of an example pattern are shown in Fig. 2. For this example the sum of the interpulse intervals of the four flashes in the pattern is 6.7 s, and the flash pattern interval is specified as 10 s, so all of the LEDs are kept dark for an additional 3.3 s after the fourth flash (that is, the second occurrence of flash #1) ends.




Figure 2: *pattern* timeline

The commands shown below could be used to completely configure the pattern shown in Fig. 2. Assume that the same physical LED is used for all of the flashes, and that this LED is connected to channel 5. Three virtual LEDs are first defined, all of which use the same channel but have different maximum brightness levels (53% for flash #7, 87% for flash #4, and 100% for flash #1, respectively). Then the three flashes are defined with the desired

timing parameters. Note that flash #4 has a value of zero for its down duration, so the LED instantly changes from full illumination to fully dark. The interpulse interval for flash #3 is also exactly equal to the up duration plus the on duration, so the next flash can begin immediately after the LED is turned off.

The pattern itself is defined using the 'P' command. This command has a minimum of three fields: the pattern number, the flash pattern interval, and the flash number of a single flash that will be executed in the pattern. Additional members of the flash list are appended as comma-separated values, so the command may have a total of 18 fields if a list of 16 flashes is included in the pattern. The command shown in this example configures pattern #2 to have a flash pattern interval of 10 s and to begin by executing flashes #1, #4, #7, and #1.

```
L,1,5,53

LED Configured

L,2,5,87

LED Configured

L,3,5,100

LED Configured

F,1,3,300,800,300,2300

Flash Configured

F,4,2,300,700,0,1000

Flash Configured

F,7,1,50,150,100,1100

Flash Configured

P,2,10000,1,4,7,1

Pattern Configured
```

Attempting to configure a pattern number that is already configured will cause the new definition to replace the existing definition, without warning. The pattern configuration command will fail if

- the pattern number is out of range (1 to 16 for the Arduino UNO), or
- any of flashes given in the flash list has not been configured, or
- the flash pattern interval is greater than 32.767 ms, or
- the flash pattern interval is zero, or
- the flash pattern interval is less than the sum of the interpulse intervals for the flashes in the flash list.

The DP (Dump Patterns) command will list all of the patterns that have been configured in the simulator. There are no additional fields for this command. All configured patterns are listed, in numerical order. Note that pattern #4 has not yet been configured in this example.

```
DP
p,1,7500,1,2,3
p,2,10000,1,4,7,1
p,3,5000,3,3
p,5,32100,16
```

The XP (eXecute Pattern) command can be used to execute a single specific pattern. This command has one field, the pattern number. The specified pattern will be executed repeatedly and the simulator will not accept any further commands; the ABORT button must be pressed to terminate this command. The simulator sends a message back to the host computer before beginning each execution of the selected pattern. This response message begins with the letter 'p' and has three additional fields: the current data and time (UTC), the current Celsius temperature, and the pattern number for the pattern that is about to begin.

```
xP,2
p,2019-05-29T18:12:44Z,22,2
p,2019-05-29T18:12:54Z,22,2
p,2019-05-29T18:13:04Z,23,2
p,2019-05-29T18:13:14Z,22,2
and so on...
```

#### **Random Pattern Sets**

A *random pattern set* is simply a set, or list, of unique pattern numbers. The firefly simulator will repeatedly execute these patterns, using a pseudorandom number generator to select the next pattern to be executed

The command message used to configure a random pattern set begins with the letter 'R' and has a minimum of 2 fields: the random pattern set number and the pattern number for a single pattern to be executed. However, a random pattern set with a single pattern will behave exactly like an XP (eXecute Pattern) command that specifies the single pattern. A practical random pattern set command will have up to 17 fields: the random pattern set number and up to 16 pattern numbers. Note that the order that the pattern numbers are given in the pattern set is not significant, but a given number must not be repeated.

For example, the command shown below will configure random pattern set #4, which will randomly execute patterns #1, #2, and #5.

```
R,4,1,2,5
Random Pattern Set Configured
```

Attempting to configure a random pattern set number that is already configured will cause the new definition to replace the existing definition, without warning. The random pattern set configuration command will fail if

- the random pattern set number is out of range (1 to 16 for an Arduino UNO), or
- any of patterns given in the pattern list has not been configured.

The DR (Dump Random pattern sets) command will list all of the random pattern sets that have been configured. This command has no parameters.

```
DR
r,2,3,5,13
r,3,1,2,3,4
r,4,1,2,5
```

The XR (eXecute Random pattern set) command can be used to execute a specific random pattern set. This command has one field, the random pattern set number. The patterns specified in the random pattern set will chosen at random and executed repeatedly until the ABORT button is pressed. The simulator sends a message back to the host computer before beginning each execution of a selected pattern. This response message begins with the letter 'p' and has three additional fields: the current data and time (UTC), the current Celsius temperature, and the pattern number for the pattern that is about to begin.

```
XR,4

Generating Random Patterns
r,4,1,2,5
p,2019-05-30T15:33:26Z,23,5
p,2019-05-30T15:33:59Z,22,1
p,2019-05-30T15:34:06Z,22,2
p,2019-05-30T15:34:16Z,22,5
p,2019-05-30T15:34:49Z,22,1
and so on...
```

# Using the Keypad

The firefly simulator's built-in keyboard can be used to execute a single pattern repeatedly or to execute a random pattern set. Pressing the asterisk '\*' key followed by a digit key from 1 to 9 has exactly the same effect as entering the XP, n command from the host computer, where n is the digit key that was pressed. Similarly, pressing the number sign '#' key followed by a digit key from 1 to 9 has exactly the same effect as entering the XR, n command.